


BMW F900R ID 90205312/90205317




Installing:

Left side:







Comments:

- 1. Contact a specialized service, do not install the cage yourself!
- 2. Remove the original bolt in point #1
- 3. Attach left side of cage to points #1 and #3
- 4. Screw lightly left side of cage with the M12x120 Bolt in point No. 1 and with the M12x100 Bolt in point No. 3
- 5. Remove the original bolt at point #2
- 6. Attach right side of cage to points #2 and #4
- 7. Screw lightly right side of cage with the M12x120 Bolt at point No. 2 and with the M12x120 Bolt at point No. 4
- 8. Install brace 295 mm between points No. 5 and No. 6 and fix it with bolts M10x1.25x30
- 9. Torque fastener according to the table.
- 10. Install Sliders at points No. 7,8,9,10 and fix them with self-tapping screws.
- 11. Install decorative caps at points No. 1,2,3 and 4.
- 12. In the case of using a damper cage, article 90205317, damper sliders are used instead of sliders at points No. 7,8,9,10. (see damper slider assembly diagram)

Tightening torques Nm					
	Connection type				
Thread	Steel	Aluminum			
M6	10	6			
M8	24	20			
M10	48	35			
M12	56	45			

Component table with according to numbers in the photo:

No			Items		7 0
	Bolt M12x120	Spring washer	Washer	Cap	
1		0	0		
	Bolt M12x120	Spring washer	Washer	Cap	
2		0	0		
	Bolt M12x100	Spring washer	Washer	Cap	
3		0	0		
	Bolt M12x120	Spring washer	Washer	Cap	
4		0	0		
	Bolt M10x1,25x30	Spring washer	Washer	Brace L=295	
5		0	0		
	Bolt M10x1,25x30	Spring washer	Washer		
6		0	0		
	Slider	Screw			
7		Ommon			
	Slider	Screw			
8		Ommin			
	Slider	Screw			
9		Ommin			
Mas	Slider	Screw			
10		Ommin .			